

dreamscape

L I G H T I N G M F G . , I N C .

DL-130 / INT. 3/4"

INTERIOR MICRO WELL LIGHT FOR 3/4" **WOOD FLOOR** APPLICATION



Lamp

20 Watt MR-11 Halogen
DC Base - 12 Volt

Height - 5 1/2"

Width - 3 1/4"

Base - 2"

Construction

Spun Aluminum Housing
Solid Brass Faceplate

Electrical - 12 Volt

Ordering Guide

DL-130/INT. 3/4 x 3/4 - Wood Finish

Top Plate Finishes:

- Verde - 1
- Pewter - 2
- Copper Bronze - 3
- White - 4
- Ancient Bronze - 5
- Brass Bronze - 6
- Custom - 7
- Copper Plate - 8
- Ancient Verde - 9

MADE
IN
USA

5521 West Washington Blvd., Los Angeles, CA 90016 USA

Ph: 323-933-5760 Fax: 323-933-3607

www.dreamscapelighting.com

E-mail: info@dreamscapelighting.com

NEW

DL-130 INT. 3/4" WOOD FLOOR INSTALLATION GUIDE

INTERIOR MICRO WELL LIGHT 3/4" WOOD FLOOR APPLICATION



INTERIOR UPLIGHT FOR 3/4" SUB-FLOOR & 3/4" FINISH FLOOR

DL-130 INT 3/4" Wood Floor

1. Drill a 2 1/4" hole in 3/4" plywood. Drop housing through hole and mark where eyelets in housing contact the top of the plywood. Drill a 1/4" hole below each eyelet to allow finish faceplate screws to pass through plywood subfloor to space below.
2. Take a fully assembled fixture with the faceplate installed, and drop it into the hole created in the subfloor. Now measure to the top of the finished faceplate to make sure it is flush with the finish surface dimension. If necessary, route plywood to reduce height of fixture or shim from below to raise the height.
3. Install wire connector in bottom hole of housing. Pull wire rated for at least 105 degrees Centigrade up through hole in the plywood. Pass wire through connector into housing and secure wire in the housing. Drop housing into the hole.
4. Drop supplied extension collar into housing and screw completed assembly to plywood subfloor using the three open holes provided in housing and extension collar.
5. Attach feed wire to socket leads of lampholder cup. Install 20 watt flood or spot into socket. Push completed assembly fully into housing. Drop the two supplied louvers on top of the lamp.
6. Place the lens holder on top of the Housing. Then place the lens on top of the holder.
7. Place faceplate on top with the 3 holes lined up over the eyelets. Screw down faceplate with the supplied screws.
8. Cut a 3 1/4" hole in 3/4" finish wood flooring to create a space for the lighting fixture.
9. Install finish floor.

MADE IN USA

IMPORTANT: Silver louver sits on top of the lamp, and the black louver sits on top of the silver louver.